TM22 STANDARD



USERS MANUAL



WARNING: READ THE INSTRUCTIONS AND SAFETY PRECAUTIONS IN THIS MANUAL CAREFULLY BEFORE USING THE FIREARM.

ROCK ISLAND ARMORY

USERS MANUAL TM22 STANDARD SAFETY, INSTRUCTION AND PARTS MANUAL



As a responsible owner of this firearm, you must read the instructions and warnings in this manual carefully. Before using this firearm, make sure you understand throughly the contents of this manual.

This manual must always be in the firearms carrying case whenever the owner/user brings it or when it transfers ownership. A copy of this manual is available upon request from:

ARMSCOR PRECISION INTERNATIONAL

150 N Smart Way, Pahrump NV 89060 E-mail: support@armscor.com

TABLE OF CONTENTS





STATEMENT OF LIABILITY

This firearm is classified as a firearm or dangerous weapon. It is expressly understood that we assume no liability for its resale or unsafe handling under local laws and regulations. Armscor assumes no responsibility for physical injury or property damage resulting from either intentional or accidental discharge, or for the function of the firearm subjected to influence beyond their control. Armscor will honor no claims which may result from careless handling, unauthorized adjustments, defective or improper ammunition, corrosion or neglect. Examine your firearm carefully at the time of purchase. It should be forwarded immediately to the factory or its sales agent if any adjustment of any kind is required.

State-By-State Warnings



CALIFORNIA STATE WARNING

CHILDREN ARE ATTRACTED TO AND CAN OPERATE FIREARMS THAT CAN CAUSE SEVERE INJURIES OR DEATH, PREVENT CHILD ACCESS BY ALWAYS KFFPING FIRFARMS LOCKED AWAY AND UNI OADED WHEN NOT IN USE. IF YOU KFFP A LOADED FIREARM WHERE A CHILD ORTAINS AND IMPROPERLY LISES IT YOU MAY BE FINED OR SENT TO PRISON. IT IS UNLAWFUL TO USE A MAGAZINE WITH A CAPACITY OVFR 10 ROUNDS



MASSACHUSETTS STATE WARNING

IT IS UNLAWFUL TO CARRY ANY MAGAZINE OR BELT WHICH HOLDS MORE THAN TEN ROUNDS, UNLESS AUTHORITY IS GRANTED BY THE BOSTON POLICE COMMISSIONER. IT IS UNLAWFUL TO STORE OR KEEP A FIREARM. RIFLE, FIREARM OR MACHINE GUN IN ANY PLACE UNLESS THAT WEAPON IS EOUIPPED WITH A TAMPER RESISTANT SAFETY DEVICE OR IS STORED OR KEPT IN A SECURELY LOCKED CONTAINER



NEW YORK STATE WARNING

IT IS UNLAWFUL TO CARRY ANY MAGAZINE OR BELT WHICH HOLDS MORE THAN SEVEN ROLINIOS LINEESS ALITHORITY IS GRANTED BY THE STATE OF NEW YORK THE LISE STORAGE FOR INCREASED SAFETY, FIREARMS SHOULD BE STORED UNLOADED AND LOCKED IN A LOCATION THAT IS BOTH SEPARED FROM THEIR AMMUNITION AND INACCESSIBLE TO CHILDREN AND OTHER UNAUTHORIZED PERSONS

02 | SAFETY PRECAUTIONS

Safety must be the first and constant consideration of every person who handles firearms and ammunition. The person with a firearm in his possession has an important responsibility. He/She must know how to use his/her firearm safely:

- 1. Always keep the muzzle pointed at a safe direction. Watch the muzzle at all times. Never point a gun, accidentally or intentionally, at any person or anything you do not intend to shoot. Identify the target before shooting; do not shoot at sounds.
- 2. Always treat a gun as if it is loaded it may be!
- **3.** Keep your finger off the trigger while operating the action and at all other times until you are ready to shoot.
- 4. Keep the safety "on" or in the "safe" position at all times until you are ready to fire. Do not rely on your gun's safety, the safety on any gun is a mechanical device and is not intended as a substitute for common sense or safe gun handling.
- **5.** Learn how your gun functions and handles. If you do not thoroughly understand the proper use and care of your gun, seek the advice of someone who is knowledgeable.
- 6. Do not alter or modify any part of the firearm.
- 7. Store guns unloaded, separate from any ammunition, and out of the reach of children.
- **8.** Be sure the barrels is clear of any obstructions before loading. Make it a habit to check the barrel every time before loading.
- 9. Be sure you have and use the proper ammunition.
- **10.** Wear protective shooting glasses, adequate ear protection and gloves when shooting.
- 11. Never climb or jump over anything, such as a tree, fence, or ditch, with a loaded gun. Open the barrel, remove the shells and hand the gun to someone else or place it on the ground on the other side of the obstacle before crossing it yourself. Do not lean a gun against a tree or other object; it could fall and possibly discharge.

- 12. Do not shoot at a hard surface or at water. Bullet and shot can ricochet or bounce off and travel in unpredictable directions with great velocity.
- 13. Never transport a loaded gun. Do not place a loaded gun into a vehicle. The gun should be unloaded and placed into a case when not in use.
- **14.** Never consume intoxicating beverages and/or drugs before or during shooting.

WARNING

DO NOT ATTEMPT TO USE ANY FIREARM WITHOUT HAVING A COMPLETE UNDERSTANDING OF ITS PARTICULAR CHARACTERISTICS AND SAFE USE. READ AND UNDERSTAND THIS MANUAL CAREFULLY BEFORE USAGE OF YOUR FIREARM.

WARNING

YOU SHOULD NEVER DEPEND ON A SAFETY MECHANISM OR ANY OTHER MECHANICAL DEVICE TO JUSTIFY CARELESS AND IMPROPER HANDLING.

WARNING

THIS FIREARM WAS MANUFACTURED TO PERFORM PROPERLY WITH THE ORIGINAL PARTS AND MAGAZINES AS DESIGNED. PLEASE MAKE SURE ANY PARTS YOU BUY ARE INSTALLED CORRECTLY AND THAT NEITHER REPLACEMENTS NOR ORIGINALS ARE ALTERED OR CHANGED. PUTTING A FIREARM TOGETHER INCORRECTLY OR WITH MODIFIED PARTS CAN RESULT IN DAMAGED FIREARM, DANGER, AND INJURY OR DEATH. ANY MODIFICATIONS TO FIREARM WILL VOID FACTORY WARRANTY.

03 | SAFETY PRECAUTIONS

WARNING

CHILDREN ARE ATTRACTED TO FIREARMS, AND MIGHT BE ABLE TO OPERATE THEM, THEY CAN CAUSE SEVERE INJURIES AND EVEN DEATH, TO THEMSELVES OR OTHERS. PREVENT CHILDREN FROM ACCESS, ALWAYS KEEP YOUR FIREARMS LOCKED AWAY, UNLOADED AND OUT OF REACH OF CHILDREN WHEN NOT IN USE AT ANY TIME.

WARNING

THE FIREARM SHOULD BE STORED IN ROOMS WITH A DRY ATMOSPHERE AND MINIMUM HUMIDITY. IT SHOULD NOT BE STORED ENCASED IN LEATHER OR ANYTHING THAT WILL ATTRACT AND HOLD MOISTURE, CAUSING IT TO RUST.

WARNING

DO ALL PROCEDURES (DISASSEMBLY, CLEANING AND OTHER MAINTENANCE) ONLY WHEN THE FIREARM IS UNLOADED. BE SURE THAT THE MAGAZINE TUBE, RECEIVER AND CHAMBER ARE EMPTY WHILE YOU ARE PROCEEDING. CHECK EJECTION PORT, LOADING PORT AND CHAMBER VISUALLY.

WARNING

WHEN STORING THE GUN FOR A PROLONGED PERIOD OF TIME, IT IS NECESSARY TO OIL IT HEAVILY WITH AN ACID-FREE LUBRICANT. THE EXTERNAL PARTS MUST BE COATED WITH AN ANTI-RUST OIL OR GREACE TO PREVENT MOISTURE CAUSING THE PARTS TO RUST AND MALFUNCTION. BEFORE USAGE, THE FIREARM MUST BE CLEANED AND WIPED DRY AGAIN.

04 | TECH SPECS

Model	TM22 STANDARD
Caliber	.22LR
Action	Semi Automatic
Capacity	10 Rounds
Barrel	Contoured
Dallel	Contoured
Barrel Length	470mm / 18.5" & 500mm / 20"
Overall Length	925mm / 36.4" & 955mm / 37.5"
Overall Width	153mm / 6.2"
Length of Pull	350mm / 13.7"
Weight, Empty	1.7kg / 3.7lb 2kg / 4.4lb.
Weight, Loaded	1.8kg / 3.9lb 2.1kg / 4.6lb.
Stock	Fixed AG Stock



05 | BASIC PARTS


	DESCRIPTION OF THE PROPERTY OF
P.NO	PART NAME
1	Polymer Stock
2	Safety
3	Safety Pin
4	Safety Pin Spring
5	M4X4 Screw
6	Trigger Group
7	Magazine Release Lever
8	Magazine Release Lever Spring
9	Magazine Adapter
10	Magazine Adapter Pin
11	Magazine Release Lever Pin
12	Ejector Spring
13	Ejector
14	Ejector Pin
15	Trigger
16	Trigger Insert
17	Front Sight & Trigger Insert Pin
18	Front Sight & Trigger Insert Pin
19	Disconnector Spring
20	Disconnector
21	Trigger Spring
22	Trigger Pin & Hammer Pin
23	Hammer
24	Hammer Pin Sleeve Female
25	Hammer Pin Sleeve Male

P.NO	PART NAME
26	Hammer Spring
27	Trigger Pin & Hammer Pin
28	Upper Receiver
29	Rear Sight
30	Rear Sight Spring
31	Rear Sight
32	Right Left Rear Sight Setscrew
33	Recoil Spring Docking Pin & Rear Sight Pin
34	Sight Pin
35	Sight Spring
36	Rear Sight Spring Setscrew
37	Bolt
38	Right Extractor Spring
39	Right Extractor
40	Extractor Pin
41	Left Extractor Spring
42	Left Extractor
43	Extractor Pin
44	Firing Pin Spring
45	Firing Pin
46	Firing Pin Reteaning Pin
47	Bolt Pin
48	Bolt Screw
49	Charging Handle
50	Charging Handle Screw

P.NO	PART NAME
51	Recoil Spring Pin
52	Recoil Spring
53	Recoil Spring Docking
54	Recoil Spring Pin & Rear Sight Pin
55	Rubber
56	18" Barrel
57	Barrel Centering Pin
58	Plastic Front Sight Receiver
59	Front Sight Set Setscrew
60	Front Sight Spring
61	Front Sight
62	Front Sight & Trigger Insert Pin
63	Barrel Pin
64	Trigger Group Assemble Nut M4
65	Trigger Group Assemble Nut M4
66	Stock Assemble Nut M6
67	Trigger Group Assemble Screw
68	Trigger Group Assemble Screw
69	Lower Receicer Assamble Screw
70	Recoil Pad
71	Stock Screw
72	Front Pkatin Cover
73	Grip Cover
74	Magazine
75	Magazine Follower

P.NO	PART NAME	
76	Magazine Spring	
77	Magazine Base Plate Lock	
78	Magazine Base Plate	

Note: Some models will vary from exploded view.



DISASSEMBLY OF THE FIREARM

- 1) Ensure the magazine is detached from the firearm.
- **2)** Using a 5mm Allen key, remove the screw located under the handguard.





- 3) Gently separate the lower receiver from the upper réceiver.
- **4)** Using a 3mm Allen key, remove the front screw located under the upper receiver.





- 5) Using a 3mm Allen key, remove the rear screw located under the upper receiver.
- 6) Pull the barrel in arrow direction.





DISASSEMBLY OF THE FIREARM

- 7) Using a 3mm Allen key, unscrew the Charging handle screw.
- 8) Pull the Charging handle out from its slot.



- 9) Using a rubber mallet and a thin iron stick, gently tap out the rear pin from the upper receiver.
- **10)** Slowly remove the cap from the upper receiver, allowing the spring to come out.





- 11) Remove the bolt from the upper receiver.
- 12) Proceed to clean and lubricate the parts as shown in the image.





ASSEMBLY OF THE FIREARM

- 1) Place the bolt into the upper receiver.
- 2) Align the spring and its cap in sequence.



- **3)** Using a rubber mallet, gently tap the rear pin back into place.
- 4) Insert the Charging handle into its slot.





- **5)** Use a 3mm Allen key to tighten the Charging Handle screw.
- 6) Place the trigger group into position.





ASSEMBLY OF THE FIREARM

- 7) Use a 3mm Allen key to tighten the rear screw located under the upper receiver.
- **8)** Use a 3mm Allen key to tighten the front screw under the upper receiver.



- **9)** Attach the lower receiver to the upper receiver.
- **10)** Using a 5mm Allen key, tighten the screw located under the handguard.







HOW TO SWITCH YOUR CHARGING HANDLE TO THE SIDE

- 1) Use a 3mm Allen key to unscrew the Charging Handle screw.
- 2) Remove the Charging handle, then screw it into the corresponding slot on the opposite side.





SAFETY GUIDE

PICATINNY RAIL

ACCESSORIES

1) The "safety" in the on safe position.

2) The "safety" in the off safe position.



A Picatinny rail is located under the removable fore-end cap.



Accessories are available on the aftermarket. Visit **advancedtactical.com** to explore more options.










ORDERING PARTS

Visit RIA website to browse, learn more about and purchase parts and ammunition for all of your Rock Island Armory products.













13 | WARRANTY

WARRANTY REGISTRATION

Armscor's warranty covers its firearms and parts. We offer limited lifetime warranty on our products for their intended purpose. As with any product, abuse, gunsmitting by an unqualified person and normal wear and tear are excluded. Additionally, if the firearm was modified and/or repaired by an unqualified gunsmith without permision from Armscor, then the warranty will be void. If warranty work should be required, return the firearm to the address listed below. There is no refund for the shipping cost. Gunsmithing services are available by registered Armscor Gunsmithers. Please email the address below.

To register your firearm, please go to www.rockislandarmory.com/support-center/warranty/ and complete online warranty form. In comments section, write warranty registration and press submit. You can also go to www.rockislandarmory.com and press warranty section at the bottom.

For more information on warranty, visit www.rockislandarmory.com, or email support@armscor.com

Armscor Precision International 150 North Smart Way Pahrump, NV 89060 Email: support@armscor.com

IMPORTANT WARRANTY INFORMATION

Our Rock Island Armory firearms are warranted to function only with Factory Ammo and the Original Factory Magazine. Use of Handloads is not covered in Warranty of Repair for the function of the Firearm.

DUE TO THE FIT AND TIGHTNESS OF FIREARM, RIA RECOMMENDS A BREAK-IN PERIOD OF 500 ROUNDS.

THIS IS HOW YOU VOID YOUR WARRANTY

- * Refinishing your RIA firearm
- * Misuse, Mishandling, Dropping your RIA Firearm
- * Firing Remanufactured or Reloaded Ammunition
- * Not properly reassembling your RIA Firearm resulting in damage, ie reverse plugs!
- * Any addition of after market parts
- * Unauthorized repairs done by any other than Rock Island Armory

LIMITS ON WARRANTY (will not cover)

- * Finish, Holster wear, Scratches, Chemical damage
- * After Market Magazines
- * Damage to Factory Magazines
- * Sights not installed by Rock Island Armory
- * Recoil Springs

WE RESERVE THE RIGHT TO CHARGE FOR LABOR, PARTS AND SHIPPING TO RETURN YOUR RIA FIREARM BACK TO FACTORY SPECIFICATIONS IF IT HAS BEEN ALTERED.

14 NOTES	KEEP THIS CARD FOR YOUR RECORDS
	Serial Number Date Of Purchase Place Of Purchase

IMPORTS

www.rockislandarmory.com